

PROFESSIONAL AUDIO SYSTEM

CT5



OPERATING MANUAL

Ver. CT5-EN-1.1

NOTICE:

LSS products are manufactured for use according to proper procedures by a qualified operator and only for the purposes described in this manual. The following conventions are used to indicate and classify precautions in this manual. Always heed the information provided with them. Failure to heed precautions can result in injury to people or damage to property.

© LSS, 2016

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of LSS.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because LSS is constantly

striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, LSS assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.



SUMMARY

INTRODUCTION	4
SAFETY AND WARNING	5
APPLICATION	6
PHYSICAL DESCRIPTION	6
TECHNICAL SPECIFICATIONS	7
INSTALLATION AND WIRING	8
WEEE DIRECTIVE	10
TROUBLESHOOTING	11
DIMENSIONS	12
NOTES	13

INTRODUCTION

Congratulation on the purchase of your new LSS loudspeaker.

Quality innovation and versatility, this is a summary of the new system developed by LSS for professional sound users.

LSS produces professional audio products – the result of exceptional engineering and meticulous craftsmanship.

This manual is intended for use with LSS loudspeaker. This includes: safety precautions; installation, set-up and operating instruction.

Please read this manual plus any accompanying manual and follow all relevant precautions and instructions. This should allow you to obtain the maximum performance from your new loudspeaker.

Where there are conflicts or overlaps, the information in any accompanying manual supersedes the information in this manual.



SAFETY AND WARNING

IMPORTANT! SAFETY WARNING!

In the interest of their own and others' safety and to prevent voiding the warranty, we recommend a careful reading of this section before using the product.

- This product was designed and manufactured to be used as a speaker system in the context of a typical sound reinforcement system.

The use for any purpose other than these is not provided by the manufacturer and is therefore under the direct responsibility of the user / installer.

- This device complies with class I (must be connected to the outlet with a protective earthing connection).





TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER SERVICEBLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE

TO AVOID THE RISK OF FIRE AND / OR ELECTRIC SHOCK*:

- Do not expose this system to rain or moisture. Do not expose the apparatus to dripping or splashing water. Do not place objects filled with liquids, such as drinks, on the apparatus.
- Before connecting the system, be sure the mains voltage corresponds to that stated on the product.
- Connect this appliance to a power outlet with earth contact, according to national security force, via a power cable of adequate section ends with a plug or connector that meets the applicable safety regulations.
- The unit is connected to the network even when the power switch is in position '0' (OFF). Before any maintenance, disconnect the power cable from the outlet.

IMPORTANT! SAFETY PRECAUTIONS!

Read This First.

Read and heed all warnings and safety instructions in this Manual before using the

Failure to follow all precautions can result in equipment damage and / or personal injury.

- 1. Read these instructions.
- 2. Keep these instructions
- Heed all warnings and follow all instructions.
- 4. Use only attachments/accessories specified by the manufacturer.
- 5. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 6. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 7. LSS loudspeakers can produce sound levels capable of causing permanent hearing damage from prolonged exposure. The higher the sound level, the less exposure needed to cause such damage

CAUTION: This product is energized as long as it is connected to the AC.

CAUTION: Allow at least six inches of free space all around the amplifier for sufficient ventilation.


^{*}Risk of electric shock only for self-powered system.

APPLICATION

LSS's CT5 is a full range ceiling speaker designed vor vocal and music reproduction. The principal characteristics that countersign this product are: 130 mm double cone driver with waterproofed membrane to exponential profile, low distortion, extremely linear frequency response in vocal range, elevated dispersion, coated painted steel grille, easy fixing.

CT5 ceiling speaker was designed for fixed installation support music and paging reproduction in restaurants, hotels, bars, commercials centre, etc.

PHYSICAL DESCRIPTION



- [A] Speaker
- [B] Steel Protection Grid
- [C] Enclosure Cabinet

- [D] Fastening Hook
- [E] Transformer
- [F] Fastening Hook


Materials and construction meet the highest professional standards to ensure maximum reliability.




TECHNICAL SPECIFICATIONS

	1	
PHYSICAL	Dimensions mm (±1 mm) [Inches]	External Diameter 202.5 [7.97"]
		Cut out 164.5 [6.48"]
		Depth 67 [2.64"]
	Weight Kilograms	Net Weight 1.1
		Shipping Weight 1.3
SYSTEM PERFORMANCE	Frequency Response	±5 dB 120 Hz ~ 18 KHz
		-10 dB 100Hz
	Sensitivity (1 Watt @ 1 m)	Full Range Passive 88 dB
	Max SPL Calculated (Power AES) [PEAK]	101 dB [107]
	Nominal Input Impedance (Ω)	Full Range Passive 8 Ω
	Power Handling (Watt cont. AES) [PEAK]	Full Range Passive 20 W [80 W]
	Transformer Tapings 100V Line (W)	20 - 10 - 5 (W)
	Peak Power (W)	80 W
	Nominal Dispersion (@ -6	Horizontal 100°
	dB)	Vertical 100 °
MECHANYCAL	Enclosure material	Plastic
	Finish	White
	Suspension	Fastening Hook
	Grille	Powder coated perforated steel with anti-dust foam
	Connectors	Screws


INSTALLATION AND WIRING





Carefully unpack the contents of the box and ensure that all parts are accounted for before beginning installation.

Make a hole on the surface equal to the distance of cutouts, cut the mounting hole using a suitable saw.





Once the hole is cut, remove the protective metal grille and insert the speaker in the hole.

Make sure the fastening hooks are unscrewed.

Tighten the fastening screws in a clockwise direction until the speaker is locked.



Insert the protective grill.

Make sure that the shape and extent of the supporting surfaces are such as to ensure a safe support.

Before making connections between mixer and speakers, make sure the mixer volume is turned down.

The connection panel is a terminal block with 4 inputs:

C: Common;

20W: 20 Watts Input; 10W: 10 Watts Input; 5W: 5 Watts Input;

Power Tap is 100V.

Connect the negative wire from the amplifier in the Common Input, then connect the positive wire in one of the other inputs selecting the desired Power Handling.

You can now use the system.

WEEE DIRECTIVE

WEEE Directive

Warning!

The product is marked with this symbol which indicates not to discard electrical and electronic equipment via the normal procedure for disposal of household waste. For these products there is a diverse collection system in accordance with legislation that requires proper treatment, recovery and recycling of used products. For more information please contact the appropriate local authority.

The black bar underneath indicates that the product was placed on the market after 13 August 2005.



For home users

In the European Union

Warning: To dispose of this equipment, do not use the ordinary dust bin! The electrical and electronic equipment must be treated separately and in accordance with legislation that requires proper treatment, recovery and recycling of used products. Following the implementation by member states, private households within the EU can give free electrical and electronic equipment to designated collection facilities *.

In some countries (*), your local retailer may withdraw the old product for free if you purchase a new one of similar type.



In countries outside the EU: please contact your local authorities and ask for the correct method of disposal.

In Switzerland: Used electrical or electronic equipment can be returned free of charge to the dealer, even if you do not purchase a new product.

Further collection facilities are listed on the homepage or www.swico.ch. www.sens.ch.

For professional users

In the European Union

Warning: If the product is used for business purposes, the following steps to delete it:

contact your LSS dealer for information about the product recall.

Might be charged for the costs of collection and recycling. Small products (and amounts) might be taken back by your local collection facilities.

In Spain: contact the established collection system or the local authority for collection of used products.

In countries outside the EU: please contact your local authorities and ask for the correct method of disposal.






TROUBLESHOOTING

Problem	Possible cause (s)	Action
Amplifier		Connect a known working test speaker to the amplifier outputs. If there is no sound, check that all the electronics are on, the signal routing is correct, the source is active, the volume is turned up, and so on. Correct/repair/replace as necessary. If there is sound, the problem is in the wiring.
1. No Sound	Wiring	Verify that you have connected the correct wire pairs to the amplifier. Play something at low level through the amplifier (for example, from a CD player or tuner). Connect the test speaker in parallel with the malfunctioning line. If the sound level has gone or is very weak, the line has a short in it (possibly a severe scrape, pinch, or staple puncture). If the sound level is normal, the wire is open (possibly a cut wire or a missed connection). Using the test speaker, move down the line and test each connection/junction until you find the problem and correct it. Observe proper polarity.
2. Poor Low Frequency Response	Speakers wired out- of-polarity	When two speakers are connected out of polarity, the low frequencies will cancel each other acoustically. Carefully observe the wire markings or tracers on your speaker wires. Verify that the amplifier (+) terminal is connected to 20W or 10W or 5W input and the amplifier (-) terminal is connected to Common Input.
Intermittent output such as crackling or distortion	Faulty Connection	Check all connections at amplifier and speakers to ensure they are all clean and tight. If the problem persists, it may be in the amplifier or wiring. See Problem 1 above.
4. Constant noise such as buzzing, hissing, humming	Defective amplifier or other electronic Devices	If the noise is present but no program material is playing, the likely cause is the signal chain in the electronics. Evaluate each component as necessary to isolate the problem.
	Poor system grounding or ground loop	Check and correct the system grounding, as required.

DIMENSIONS



.....

LSS ADVANCED SPEAKERS SYSTEMS

NOTES

CT5_



CONTACT INFORMATION:

Via On. Longo 53
89024 Polistena (RC) ITALY
Tel (39) 966 9321299 – Fax (39) 966 933007
Email: info@lss.it - Internet: www.lss.it